



A - Left Accumulator Position Switch
B - Upper Accumulator Sensor (receiver)
C - Rockshaft Position Sensor
D - Upper RMB Speed Sensor
E - Lower RMB Speed Sensor
F - Gate Position Sensor
G - Wrap Hoist Proximity Sensor
H - Wrap Separation Sensor
I - Left Gate-in-Handler Switch
J - Bale-on-Handler Sensor (receiver)
K - Ladder Position Switch
L - Wheel Angle Sensor
M - Left Gate Latch Switch
N - RMB Lock-Unlock Switches
O - Metering Roller Speed Sensor
P - Beater Roller Speed Sensor
Q - Feeder Belt Speed Sensor
R - Header Height Sensors
S - Front Drum Speed Sensor
T - Rear Drum Speed Sensor

